The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.

1 A3 *********** DATA TABLE

STANDARD GROUPS

1 A7 ********* VALUE

FICHE LOCATION


ILLUSTRATION

1 A7 ********* CAMSHAFT 1 All ******** CARBURETOR PARTS 1 A13 ******** CARRYING FRAME AND BATTERY 1 A9 ********* CONNECTING ROD AND FISTON 1 B3 ********* CONTROL 1 A7 ******** CRANKSHAFT AND FLYWHEEL 1 A5 ******* CYLINDER BLOCK, OIL BASE AND GEAR COVER 1 B1 ******* DOLLY-OFTIONAL 1 All ******** FUEL SYSTEM 1 B1 ******** FUEL SYSTEM (LPG)-OPTIONAL 1 B5 ******** GENERATOR 1 A13 ********* GOVERNOR AND THROTTLE 1 A13 ******* HOUSING, STOP BUTTON AND GAGE 1 A9 ********* IGNITION 1 A13 ******** PUMP PARTS, FUEL 1 All ********* PUMP, OIL

927-1060 225 AMP WELDER - CCK SERIES PARTS CATALOG

This catalog applies to the 225 Ampere Welder. Parts are arranged in groups of related items. Each illustrated part is identified by a reference number corresponding to the same reference number below the illustration. Parts illustrations are typical. Unless otherwise mentioned in the description, parts are interchangeable between models. Right and left welder sides are determined by facing the engine end (front) of the welder.


The Specification Letter, which completes the specification on the nameplate (Example: 7.0CCK-381E/1J) advances (A to B, B to C etc.) with manufacturing changes. Welders with the suffix numbers 4323, 4324, 4325, or 4443 (following the diagonal line) are the same as number 1, except the paint color.




REF.	PART	QTY.	PART	REF.		QTY.	PART
NO.	NO.	USED	DESCRIPTION	NO.	<u>NO.</u>	USED	DESCRIPTION
1	509-0008	!	Seal, Governor Shaft	25	110-1283	1	*Cover, Timing Control - Spec J
2	510-0013	ı	Bearing, Governor Shaft - Upper				through M
3	150-0377	ı	Shaft and Arm, Governor	25 A	517-0048	ı	Plug, Camshaft - Expansion -
4	150-0236	1	Yoke, Governor Shaft	-			Begin Spec L
5	518-0129	1	Ring, Yoke Retainer	26	520-0114	- 5	*Stud, Rear Bearing Plate Mountin
6	516-0130	ļ	Pin, Roll - Governor Cup Stop		*		- 5/16 x 1 - 5/16"
7	510-0008	ł	Bearing, Governor Shaft - Lower	27	110-0445	5	*Nut, Rear Bearing Plate
8	510-0014	1	Ball, Bearing - Governor Shaft	28	851-0005	5	*Washer, Lock - 5/16 x Special
9	509-0040	1	Seal, Oil - Gear Cover				Width - Rear Bearing Plate
10	150-1000	ł	Extension, Governor Arm - Fastens	29	102-0440	j	Base, Oil
			to Governor Arm	29A	123-0901	1	Tube, Oil Fill
11	815-0181	1	Screw, Self Tapping - Bracket	30	123-0882	I	Cap, Oil Fill - Includes Cap
			Fastening - 10-32 x 1/2"				Gasket & Oil Level Indicator
12	103-0207	1	Cover Assembly Gear - includes	31	123-0191	i	Gasket, Oil Fill Cap
			Cover plus items I through II	32	102-0158	ı	Gasket, Oil Base Mounting
13	103-0011	t	Gasket, Gear Cover	33	ELBOW, OH	L DRAIN	
14	110-1516	1	Block Assembly Cylinder Includes		505-0120	1	Early Models 3/8" - 90°
			Parts Marked *		505-0050	1	Later Models 1/2" - 90°
15	516-0011	2	*Pin, Gear Cover - 5/16 x 1-1/8"	34	NIPPLE, OI	L DRAIN	
16	120-0386	1	*Tube, Oil - Crankcase Internal,	1	505-0125	ŀ	Early Models 3/8 // x 6 //
			To Rear Main Bearing	1	505-0082	l	Later Models 1/2"x 5-1/2"
17	123-0293	ŀ	Cap, Breather Tube Rubber	35	COUPLING	, OIL DRA	IN
18	123-0129	1	Tube, Breather - Less Valve &	1	505-0028	J	Early Models 3/8
			Baffle		505-0014	i	Later Models 1/2"
21	123-0104	t	Valve, Breather Tube	36	504-0080	ł	Valve, Oil Drain - 3/8'
22	110-0666	2	Cover, Valve Compartment	37	502-0020	1	Elbow, Street - Oil Line to Block
23	110-0667	2	Gasket, Valve Complete Cover	38	110-0892	2	Gasket Cylinder Head
24	526-0063	2	Washer, Copper - Valve Complete	39	110-0884	1	Head, Cylinder - RH
			Cover	40	110-0883	1	Head, Cylinder - LH
				* .	- Parts Includ	ded in Cyli	inder Block Assembly.

NO. NO. USED DESCRIPTION 41 *BEARING KIT, CRANKSHAFT - PRECISION	linder Head linder Head ar Cover ar Cover
101-0420 2 Standard 57 800-0011 2 1/4-20 x 2 " - Valve Color 101-0420-02 2 .002" Undersize 58 110-0879 8 5/16-18 x 1-1/4" - Cyl 101-0420-30 2 .020" Undersize 59 114-0022 10 5/16-18 x 1-3/4" - Cyl 42 104-0575 2 Washer, Crankshaft Bearing Thrust - Included in Bearing 60 800-0032 4 5/16-18 x 1-3/4" - Geign 57 800-0011 2 1/4-20 x 2 " - Valve Color Cover Mounting 58 110-0879 8 5/16-18 x 1-1/4" - Cyl Mounting 59 114-0022 10 5/16-18 x 1-3/4" - Geign 59 114-0022 10 5/16-18 x 1-3/4" - Geign 60 800-0032 4 5/16-18 x 1-3/4" - Geign 60 800-0032 60 800-0	linder Head linder Head ar Cover ar Cover
101-0420-02 2 .002" Undersize Cover Mounting . 101-0420-10 2 .010" Undersize 58 110-0879 8 5/16-18 x 1-1/4" - Cyl 101-0420-20 2 .020" Undersize Mounting . 101-0420-30 2 .030" Undersize 59 114-0022 10 5/16-18 x 1-3/4" - Cyl 42 104-0575 2 Washer, Crankshaft Bearing Mounting . Thrust - Included in Bearing 60 800-0032 4 5/16-18 x 1-3/4" - Gei	linder Head linder Head ar Cover ar Cover
101-0420-10 2 .010	linder Head ar Cover ar Cover
101-0420-20	linder Head ar Cover ar Cover
101-0420-30 2 .030 Undersize 59 114-0022 10 5/16-18 x 1-3/4 '' - Cyl 42 104-0575 2 Washer, Crankshaft Bearing Thrust - Included in Bearing 60 800-0032 4 5/16-18 x 1-3/4 '' - Gei	ar Cover
42 104-0575 2 Washer, Crankshaft Bearing	ar Cover
Thrust - Included in Bearing 60 800-0032 4 5/16-18 x 1-3/4 * - Gei	ar Cover
Kit	
43 516-0072 4 Pin, Crankshaft Thrust Washer 61 800-0034 1 5/16-18 x 2-1/4 "- Gea Lock - Included in Bearing Mounting	
Kit 62 102-0455 4 3/8-16 x 1-1/4 " - Oil E	3ase Moun
44 101-0115 *Gasket Kit, Rear Bearing Plate 63 800-0037 2 5/16-18 x 3 " - Engine	Mounting
45 101-0316 1 *Plate, Rear Bearing 64 800-0050 2 3/8-16 x 1 " - Generator (Less Bearing) Mounting	or Support
46 101-0367 2 *Bearing, Camshaft - Front & Rear 65 526-0076 2 Washer, Flat - Generati	or Mtg.
47 505-0019 ! Bushing, Reducer Oil Drain (11/32)	
(1/2" to 3/8") - Later Models 66 526-0076 4 Washer, Flat - Engine 1 Only (11/32)	Mtg.
48 509-004! I Seal, Oil - Rear Bearing Plate 67 526-0080 2 Washer, Flat - Generato	or Support
49 232-1368 Support, Generator (3/8)	
CUSHION ASSEMBLY, PLANT MOUNTING 68 850-0050 2 Washer, Lock - Generat	tor Support
50 402-0226 2 Engine End (3/8)	
51 402-0223 2 Generator End 69 850-0045 5 Washer, Lock - Gear Ca	ase Mtg.
52 402-0038 2 Cushion, Mtg. (Lower) Engine End 70 850-0050 4 Washer, Lock - Oil Bas	
53 402-0131 4 Cushion, Mtg. (Upper) Engine End (3/8)	
(2), Generator End (2) 71 870-0048 2 Nut, Huglock - Engine	Mtg.
54 402-0137 2 Bushing, Spacer - Engine End (5/16-18)	
55 402-0192 2 Cushion, Mtg. (Lower) Generator 72 870-0045 2 Nut, Huglock - Generat End (5/16-18)	or Mtg.
56 402-0193 2 Bushing (Sleeve), Mounting - 73 102-0558 1 Heater, Oil Base (Option	onai)
Generator End 74 141-0078 1 Gasket, Oil Fill Tube 1	Mounting


^{* -} Parts Included in Cylinder Block Assembly




REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	150-0078	1	Ring, Camshaft Center Pin Snap
2	150-0612	. 1	Cup, Governor
3	510-0015	5	Ball, Fly - Governor
4	CAMSHAFT		
	105-0234	1	Spec J through M
	105-0238	1	Begin Spec L
5	150-0075	1	Pin, Camshaft Center
6	105-0353	I	Gear Set, Timing - Includes Crank Gear, & Cam Gear with Flyball Spacer & Plate (also in Crank- shaft & Flywheel Group)
7	105-0004	1	Washer, Thrust, Cam Gear
8	515-0001	1	Key, Camshaft Gear Mounting
12	516-0144	4	Pin, Roll - 7/16" Timing Control - Spec J through M
13	160-0789	2	Weight Assembly, Includes Pins - Timing Control - Spec J thru M
14	516-0146	2	Pin, Groove - I" - Timing Control Cam - Spec through M
15	160-0726	1	Retainer, Timing Control - Spec J through M
16	110-1283	1	Cover, Timing Control - Spec J through M
17	160-0727	. 1	Spring, Timing Control - Spec J through M
18	518-0185	2	Lock, Timing Control - Spec J
19	160-0791	ļ	Cam, Timing Control - Spec J through M




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1 2 3	110-1037 110-0880 INSERT, VA 110-0872 110-1000 110-0904	2 2 LVE SEAT 2 2 4	Valve, Intake - Stellite Valve, Exhaust - Stellite I - STELLITE Exhaust Intake Rotocap, Valve	5 6 8 9	110-0902 110-0539 110-0639	4 4 8 4	Guide, Valve Spring, Valve Lock, Rotocap or Spring Retainer Washer Tappet, Valve




REF.	PART NO.	QTY. USED	PART DESCRIPTION
1 .	526-0017	1	Washer, Flywheel Mounting
2	515-0002	i	Key, Flywheel Mounting - Steel
3	104-0170	1	Screw, Flywheel Mounting
4	FLYWHEEL,	MAGNET	O - LESS ROPE SHEAVE
	160-0761	1	Spec through M
	160-0937	1 -	Begin Spec L
5	192-0308	1	Sheave, Rope
6	518-0014	f	Lock, Crankshaft Gear Washer
7	104-0043	1	Washer, Crankshaft Gear Retainer
8	105-0353	1	Gear Set, Timing - Includes Crank Gear & Cam Gear with Flyball Spacer & Plate - (Also in Camshaft Group)
9	104-0578	ł	Crankshaft
10	515-0001	ł	Key, Crank Gear Mounting
11.	192-0083	1	Rope Starting
12	850-0055	1	Lockwasher Mounting Flywheel (7/16)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
3	PISTON & PI	N ASSEM	BLY - Includes Retainer Rings	7	RING SET, P	ISTON	
	112-0073	2	Standard	ı	113-0089	2	Standard
	112-0073-05	2	.005" Oversize	1	113-0089-05	2	.005" Oversize
	112-0073-10	2	.010'' Oversize	I	113-0089-10	2	.010'' Oversize
	112-0073-20	2	.020 "Oversize		113-0089-20	2	.020' Oversize
	112-0073-30	2	.030 'Oversize		113-0089-30	2	.030 "Oversize
	112-0073-40	2	.040" Oversize	·]	113-0089-40	2	.040 "Oversize
4	112-0069	2	Pin, Piston - Specify: Std.	1 8	805-0010	4	Bolt, Place - Connecting Rod
5	112-0003	4	Ring, Piston Pin Retainer	1			Caps
6	114-0144	2	Rod, Connecting (Forged) - Includes Bushing & Place	111	114-0036	2	Bushing, Piston Pin - Connecting Rod
			Bolts	12	BEARING HA	ALF. CON	NECTING ROD
				1	114-0145	4	Standard
				1	114-0145-02	4	.002'' Undersize
					114-0145-10	4	.010´´ Undersize
			,		114-0145-20	4	.020 "Undersize
				1	114-0145-30	4	.030'' Undersize



REF.	PART NO.	QTY. USED	PART <u>DESCRIPTION</u>
. 1	160-0930	. •	Cover, Breaker Box
2	160-0150	1	Gasket, Breaker Box Cover
3	160-0075	1	Cam, Point Gap Adjusting
4	160-0002	1	Point Set, Ignition Breaker
6	312-0069	I	Condenser, Breaker Box - 0.3 Mfd.
7	336-1022	1	Lead, Breaker Box to Ignition Switch
8	160-0043	i	Gasket, Breaker Box
10	160-0723	1	Plunger Only, Breaker
10B	160-1143	1	Diaphragm, Breaker Plunger
11	167-1404	· 1	Cable, Spark Plug - RH
13	167-1403	1	Cable, Spark Plug - LH
14	160-0750	i	Coil, Magneto Stator
15	160-0749	į.	Pole Shoe, Magneto Stator
16	167-0241	2	Plug, Spark
17	160-0963	1	Box Assembly, Ignition Breaker - Includes Cover & Gasket
22	160-0428	1	Strap, Point Set to Breaker Box Terminal Block
23	160-0349	ı	Block and Terminal, Breaker Box
28	160-0261	i	Wick, Breaker Box
30	167-0188	4	Clip, Spark Plug Cable
31	160-0929	i	Bushing, Breaker Box Plunger
32	526-0015	4	Washer, Poleshoe Mounting (11/16" Thick)
33	815-0259	2	Screw, H.H. Thread Cutting Mtg. Stator (1/4-20 x 1-3/8")
34	850-0040	. 2	Lockwasher, Mounting Stator (1/4")
35	526-0184	2	Flatwasher Mounting Stator
36	815-0037	2	Screw, R.H. x Rec M W/ET Mtg. Breaker Box (1/4-20 x 7/8'')
37	812-0077	2	Screw, RHSM Mounting Breaker Box (8-32 x 3/8'')
38	850-0025	2	Lockwasher, Mounting Breaker Box (#8)






REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	145-0094	1	Inlet, Carburetor Air	15	149-0045	I	Spacer, Fuel Pump
2	503-0280	1	Clamp, Air Inlet to Air Cleaner	- 16	149-0003	2	Gasket, Fuel Pump & Spacer Mt
3	503-0107	f ·	Clamp, Air Inlet to Carburetor	17	149-0775	1	Line, Fuel Pump to Carburetor
4	140-0537	1 .	Housing, Air Cleaner	. 18	154-0601	1	Manifold, Intake
5	140-0538	1	Cover, Air Cleaner	19	141-0078	1	Gasket, Carburetor Mounting
6	140-0495	1	Cartridge, Air Cleaner	20	33 1-0053	2	Nut, Pipe - 1" - Exhaust Outlet
7	518-0056	ı	Screw, Wing - Air Cleaner Cover	21	505-0003	2	Elbow, Street - 1" - Exhaust Ou
			Mounting	22	505-0087	2	Nipple, Close - 1"x 3" - Exha
- 8	142-0416	j	Carburetor Assembly	•			Outlet
9	149-0693	J	Fump Assembly, Fuel	23	155-0484	2	Muffler, Exhaust
10	502-0002	2	Elbow, Inverted Male - (1) Fuel	24	153-0263	1	Bracket & Clip, Manual Choke
			Pump Outlet (I) Carburetor Inlet	25	154-0013	2	Gasket, Intake Manifold
11	502-0020	1	Elbow, St. Fuel Pump Inlet	26	153-0165	1	Choke, Manual
13	806-0009	2	Screw, Counterbore - 1/4-20 x	27	TANK, FUE	L	The state of the s
			1-1/4")		159-0690	1	Spec J through M
14	134-1019	<u> </u>	Baffle, Fuel Pump Air		159-0946	1	Begin Spec M


REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY.	PART DESCRIPTION
28	STRAP, FUE	L TANK	MOUNTING	37	850-0050	2	Lockwasher Intake Manifold Mtg.
	159-0692	I	Spec J through M				(3/8)
	159-0947	ŧ	Begin Spec M	38	800-0009	2	Screw, H.H. Carburetor Mounting
29	15 9- 0020	ł	Cap, Fuel Tank				to Manifold (1/4-20 x 1-1/2")
30	501 <i>-</i> 0007	1	Line, Flex Fuel - Tank to Pump	39	850-0040	2	Lockwasher, Carburetor Mtg. to
			(24'')				Manifold (1/4)
31	159-0695	1	Tube, Pick-Up - Fuel Tank Outlet	40	8/3-0100	1	Screw, RHMS Mtg. Shield (F.P.)
32	149-1170	1	Elbow & Screen, Fuel Tank				(10-32 x 1/2")
33	505-0008	i	Plug, Slotted Pipe - Fuel Tank	41	850-0030	. 1	Lockwasher Mtg. Shield (F.P.) #
			Drain	42	806-0009	ż	Screw, Counterbore Mounting Pur
34	140-0554	ł	Spacer, Air Cleaner			-	(1/4-20 x 1-1/4")
35	420-0169	1	Wrench, Carburetor Adjusting	43	856-0043	i	Washer, Shakeproof Mounting Air
36	800-0054	2	Screw, H.H. Intake Manifold Mtg. (3/8-16 x 2")			·	Cleaner (#10)

CARBURETOR PARTS GROUP




REF.	PART NO.	QTY. USED	PART DESCRIPTION
-	142-0416	1	Carburetor Assembly
E	SCREW, BOY	NL COVER	₹
	815-0103	1	#10-24 x 1/2"
	815-0109	2	#10-24 x 5/8 "
2.	815-0091	2	*Screw, Choke Fly - #4-40 x 3/16"
3 .	142-0055	1	Fly, Choke
4	142-0205	1	Sleeve, Choke (Cover)
5	142-0420	I	Shaft Assembly, Choke
6	142-0039	1	*Shaft, Float
7	142-0031	1	*Gasket, Body to Bowl
8	148-0017	2	Gasket (I) Float Valve Seat,
_			(1) Main Adj. Needle Retainer
9	142-0049	1	*Valve Seat Assembly, Float
10	142-0032	1	*Gasket, Nozzle
11	142-0285	1	Nozzle Assembly
12	142-0361	ł	Float and Lever
13	145-0008	!	Lever, Idle Stop
14	142-0040	!	*Needle, Idle Adjusting
15	142-0282	1	Spring, Idle Needle Adjusting
16	142-0035	!	Spring, Throttle Stop Adj. Screw
17	812-0063	1	Screw, Throttle Stop Adjusting - #6-32 x 1/2"
18	815-0072	2	*Screw, Throttle Fly - #4-40 x
19	142-0369	1	Fly, Throttle
20	142-0368	1	*Shaft Assembly, Throttle
21	142-0370	. 1	Nut & Jet, Nozzle
22	142-0046	1	Retainer, Main Adjusting Needle
23	142-0206	i ·	Packing, Main Adjusting Needle
24	142-0045	I	Retainer, Main Adjusting Needle Packing
25	516-0027	1	Pin, Main Adjusting Needle
26	142-0041	ŀ	*Needle, Main Adjusting
27			Body Assembly (Not Sold Separately)
28	505-0053	I	Plug, Gas Inlet
29	142-0343	2	Bushing, Throttle Shaft
30	142-0042	1	Needle Assembly - Includes Packing, Nut & Retainer
31	142-0227	ŀ	Pin, Choke Stop
	870-0053	I	Nut, Throttle Stop
	813-0102	1	Screw, Throttle Stop Clamp - 10-32 × 5/8"
	142-0033	1	*Gasket Kit, Carburetor
	142-0371	i	Repair Kit, Carburetor (Includes Parts Marked *)
		_	

^{* -} Contained in Repair Kit #142-0371.




REF. No.	PART NO.	QTY. USED	PAR [*] ; <u>DESCRIPTION</u>
	149-0693	1	Pump Assembly, Fuel
	149-0526	1	Repair Kit, Fuel Pump (Includes
			Parts Marked **)
i		1	Body, Upper (Not Sold Sep.)
2	815-0148	4	Slotted Screw, H.H. (8-32 x 1")
			Pump Assembly
3	815-0147	2	Screw, Phillips Flat Head
			(6-32 x 5/8") Valve Retainer
4	149-0096	2	**Valve and Cage
5	149-0095	2	**Gasket, Valve
6	149-0582	i	**Diaphragm Assembly
+ 7	149-0672	ı	**Spring, Diaphragm
8	149-0539	į	Retainer, Valve Cage
9	149-0675	1	**Spring, Rocker Arm
10	516-0113	ł	Pin, Rocker Arm
		İ	Body, Lower (Nct Sold Sep.)
12	149-0710	1	Arm & Link Set (Only as a Set)
13	518-0129	!	Ring, "E" Ret Priming Lever
14	149-0551	l	Lever, Hand Primer
15	509-0065	2	Seal, "O" Ring
16	149-0404	1	Spring, Priming Lever
17	149-0003	2	**Gasket, Fuel Pump & Spacer Mtg.
			(Also in Fuel System Group)
18	149-0858	1 '	**Gasket, Fuel Pump Diaphragm
			(Pull Rod Side)
** -	Contained	in Repair K	it #149-0526.




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	150-1009	* F	Stud, Governor Adjusting	10	152-0110	J	Plate, Adjusting - Speed Lever
2	150-0098	L	Spring, Governor				Travel
3	150-0974	ı	Joint, Governor Link Ball	14	526-0015	1	Washer, Flat - Speed Lever
4	150-0629	ı	Link, Governor Arm to Carburetor	15	870-0200	1	Nut, Governor Adjusting Stud
. 5	518-0006	1 1	Clip, End - Link to Carburetor	16	870-0053	1	Nut, Hex - Governor Ball Joint
6	152-0143	1	Bracket, Variable Speed Governor				to Link
7	152-0134	1	Lever, Speed Adjusting	17	870-0131	1	Nut, Keps - Governor Ball Join
8	152-0041	l	Washer, Tension - Speed Lever				to Governor Arm
9	870-0065	i	Nut, Huglock - Speed Lever - 1/4-20	18	815-0293	1	Screw Thread Cutting Mtg. Spee Control (1/4-20 x 5/8'')
				19	815-0265	I	Screw, H.H. Mtg. Speed Control (1/4-20 x 1/2")

HOUSING, STOP BUTTON AND GAGE GROUP	REF.	PART NO.	QTY. USED	PART DESCRIPTION
49	1	405-1184	ı	Cover, Engine and Control
	2	405-1187	i	Cover, Lifting Eye
	3	134-0980	ı	Housing, Cylinder Air - L.H. (#1 Cylinder)
5	4	134-1579	I	Housing, Blower
	5 _	134-0979	1,	Housing, Cylinder Air - R.H. (#2 Cylinder)
	6	501-0004	1	Line, Flexible - Oil Gauge
	7	193-0005	j	Gauge, Oil Pressure
o commun	10	502-0005	i	Elbow, Inverted Female - On Oil Gauge
	11	508-0095	2	Grommet, Rubber
	12	860-0012	2	Nut, Hex Mounting Oil Gauge (12-24)
3 610 7	13	853-0011	2	Washer, Shakeproof Mtg. Oil Gauge (#12)
16 ¹⁷	14	815-0265	2	Screw, H.H. Thread Cutting Mtg. Blower Housing (1/4-20 x 1/2")
1	15	815-0261	1	Screw, H.H. Thread Cutting Mtg. Blower Housing (1/4-20 x 7/16")
	16	815-0261	4	Screw, H.H. Thread Cutting Mtg. Air Housing (1/4-20 x 1/2")
	17	853-0013	4	Washer, Shakeproof Mtg. Air Housing (1/4)




REF.	PART NO.	QTY. USED	PART DESCRIPTION
. 1	403-0754	1	*Frame, Carrying
2	403-0588	4	Tips, Rubber - Carrying Frame
3	416-0538	1	Rack, Battery
4	337-0036	i	Strap, Ground - Carrying Frame to Blower Housing
5	416-0540	1	Frame, Battery Hold-down
6	416-0541	2	Stud, Battery Hold-down
7	416-0539	i	Battery, Starting - 12 Volt - Optional Equipment
8	CABLE, BA	ATTERY T	O CONTROL
	416-0553	i	Positive Post to Start Switch - 36"
	416-0534	I	Electrolyte, Battery

^{* -} Prior to Spec M also order (2) 159-0945 Brackets.




Citooi (Ci iloitale Edon Meitti)	DOLLY GROUP ((OPTIONAL	EQUIPMENT)
----------------------------------	---------------	-----------	------------

REF.	PART NO.	QTY.	PART DESCRIPTION
	410-0287	İ	Dolly Assembly - Includes entire group plus howe. (Does NOT include Carrying Frame)
1	410-0285	2	Handle
2	403-0205	. 2	Grip, Handle
3	4!0-0233	ŧ	Axle
4	410-0283	2	Support, Axle
5	410-0284	2 2	Plate, Axle Support
6	410-0143	2 2	Bolt, "U" - Axle Mounting
7	410-0236	2	Wheel and Tire Assy Includes Tube
8	518-0130	4	Ring, "E" Retainer - Dolly Wheel to Axle
9	526-0081	4	Washer, Flat - Wheel Mounting
10	800-0031	2	Screw, H.H. Handle Mounting (5/16-18 x 1-1/2")
11	814-0182	2	Screw, (1.H. Handle Mounting (5/16-18 x 1-1/2'')
12	800-0035	2	Screw, H.H. Handle Mounting (5/16-18 × 2-1/2")
13	850-0045	2	Lockwasher Handle Mounting (5/16)
14	862-0015	2.	Nut, Hex Handle Mounting (5/16-18)
15	850-0015	4	Lockwasher U Bolt (3/8)
16	862-0003	4	Nut, Hex U Bolt (3/8-16)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
j	502-0039	J	Elbow, Carburetor Inlet
2	159-0745	í	Line, Fuel - Vaporizer to Carb.
3	505-0099	j.	Nipple, Vaporizer to Regulator
4	148-0418	1	Vaporizer Assembly
5	148-0423	1	Bracket, Vaporizer Mounting
6	149-0136	I	Cover, Grankcase, Fuel Pump
7	502-0039	į.	Elbow, Regulator Outlet
8	148-0465	1	Regulator, LPG - Secondary
9	141-0647	ı	Carburetor, Pressure - LPG (Comb.) Carburetor & Pressure Regulator
	141-0653	1	Repair Kit, Carburetor
	141-0652	. 1	Gasket Kit, Carburetor
	141-0651	2	Seal, Throttle Shaft (Comb. of Carburetor)
	141-0650	2	Retainer, Throttle Shaft Seal (Comb. of Carburetor)



REF.	PART NO.	QTY. USED	DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
i	301-2570	1	Box, Control	23	526-0101	1	*Washer, Flat - Insulator Rod Mtg.
2	301-1340	i	Plate, Control Box Ventilation	24	868-0011	11	*Nut, Hex Jam - Jack Mounting
3	301-1339	ł	Plate, Control Box Reflector	26	304-0467	1	*Element, Resistor
4	323-0184	į	Receptacle, Duplex	27	304-0466	2	*Element, Resistor
5	303-0112	1	Rheostat	29	304-0553	1	*Element, Resistor
6	304-0061	1	Knob, Rheostat	30	304-0465	2	*Element, Resistor
· 7	304-0183	1	Resistor, Field - 5.5-Ohm, 160 Watt	31	304-0468	3	*Element, Resistor
8	304-0117	1	Bracket, Field Resistor Mounting	32	304-0554	1	*Element, Resistor
9	301-2583	1	Panel, Control Box	33	316-0045	2	Plug, Welding Cables
	RESISTOR,	BATTERY	CHARGE	34	304-0555	1	Element, Resistor
10	304-0011	ı	50-Ohm, 25 Watt (9/16 x 2 11)	35	332-0048	1	Clip, Control Leads
10A	353-0008	1	70-Ohm, 35 Watt (3/4 × 4'')	36	WASHER,	RESISTOR	CENTERING
1.1	304-0470	2	Bracket, Battery Charge Resistor		304-0015	4	1/2″J.D. x 3/4″O.D.
12	308-0028	l	Switch, Start		304-0014	2	7/32″1.D. × 9/16″ O.D.
13	308-0069	1	Switch, Ignition	37	332-0928	2	Stud, 1/4-20 x 2"
14	308-0002	j	Switch, High - Low Charge Rate	38	301-2547	i	Bracket, Terminal Board Mtg.
15	301-1778	2	*Bracket, Resistor Elements Mtg.	39	301-2548	1	Bracket, Terminal Board Mtg.
16	301-1777	l	*Block, Terminal - Resistor Element	40	332-0929	1	Board, Terminal
			Fastening	41	323-0410	J	Housing, Connector Pins (9 Plac
17	316-0044	11	* Jack, Plug - Welder Cable				 Voltage Control Leads
			Connecting	42	323-0496	7	Pin, Connector - Voltage Control
18	308-0149	10	*Angle, Connector - Resistor Elements				Leads
			to Plug jack - I-23/32 ^ Long	42A	323-0440	ı	Housing, Connector Socket (6 Pla
IBA	308-0128	3	*Angle, Connector - Resistor Elements				 Generator Leads
			to Plug Jack - 3-1/8 Long	42B	323-0488	4	Socket, Connector - Generator Le
19	304-0469	ı	*Rod, Insulator Tubes Mounting		304-0616	1	Resistor Elements & Jack Assy.
20	115-0056	1	*Spring, Insulator, Tube				 Includes Parts Marked *
21	304-0379	8	*Tube, insulator				
22	870-0173	_	*Nut, Push - Insulator Rod Mounting	* -	These part		in 304-0616 Resistor Elements and

Jack Assembly.



REF. PART QTY. PART NO. NO. USED DESCRIPTION 43 305-0425 Control, Voltage - Complete 44 315-0231 Transformer 45 323-0450 Housing, Connector Socket 46 303-0144 Rheostat 47 303-0032 Knob, Rheostat 305-0393 48 Rectifier, Bridge 49 308-0214 Switch, Toggle 50 307-0857 Relay 51 323-0196 Base, Receptacle 52 323-0484 Socket, Connector

Chassis, Voltage Control

Cover, Regulator


CONTROL GROUP

53

54

301-2771

301-2544



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART	QTY. USED	PART
1	231-0104	1		26	NO.	USED	DESCRIPTION
ic		,	Adapter, Generator to Engine	27	201-1401		Armature - AC
10	403-0642	ı	Yoke, Lifting - Mounts to Generator	28	210-0383	!	Frame, Generator - AC
ΙD	800-0029	4	Adapter	29	221-0146	2	Shoe, Pole - AC
טי		4	Screw, H.H 5/16-18 x 1-1/8"- Lifting Yoke Mounting	29	222-1675	1	Coil Assembly, Field - Set of 2 Coils - AC
2	515-0006	ı	Key, Blower to Crankshaft	30	212-0309	1	Rig, Assembly Brush - AC
3	205-0053	I	Blower, Generator	31	305-0448	I	Rectifier - AC
4	232-1256	I	Plate, Baffle	32	323-0400	1	Housing, Connector Pins (6 Plac
5	*	I	Armature Assembly - includes Blower	33	323-0500	4	Pin, Connector
			and Bearing - DC	34	203-0145	1	Commutator (#BAC45)
6	510-0072	•	Bearing, Armature (Double Sealed - Pre-Lubricated)	35	800-0050	4	Screw, H.H. Generator Adapter Mounting (3/8-26 x 1")
7	515-0122	1	Key, Drive - Blower to Armature	36	813-0098	5	Screw, R.H.M.S. Scroll, End Bell
8	232-1479	1	Clip, Bearing Stop	ĺ			$(10-32 \times 3/8'')$
9	520-0514	1,	Stud, Armature Through	37	850-0030	8	Lockwasher, Band, End Bell &
10	*	I	Coil Assembly Field - Set of 4				Scroll (#10)
			Coils, Connected - DC	38	850-0045	2	Lockwasher, Generator through
11	210-0384	1	Frame, Generator - Machined - Less				Stud 5/16
			Coils & Poleshoes - DC	39	862-0015	2 ,	Nut, Steel Hex, Generator through
12	221-0145	4	Shoe, Pole - DC				Stud (5/16-18)
13	212-0229	1	Rig Assembly, Brush - DC	40	850-0055	1	Lockwasher, Armature Stud (7/16
14	212-1105	2	Spring, AC Brush	41	862-0004	ı	Nut, Hex Armature Stud (7/16-14)
15	214-0072	2	Brush, AC	42	232-0200	1	Flatwasher, Armature Stud (7/16)
17	211-0156	1	Bell, End	43	815-0110	3	Screw, Fill Head End Bell and
18	520-0503	2	Stud, Generator Through			_	Band (10-32 x 7/8")
19	211-0157	1	Cover, End Bell	44	870-0053	3	Nut, Hex End Bell and Band
20	234-0255	1	Band, End Bell			-	(10-32)
21	222-1665	l	Coil Set, Interpole - DC				(- 0-)
22	22 1-01 44	2	Interpole - DC	* -	Order by des	cription siv	ving complete Model, Spec, and
23	212-1106	4	Spring, DC Brush	!	Serial Numbe	r.	. g =p . e te / leadily openi wild
24	214-0067	4	Brush, DC				

CPECIAL PARTS LISTS INDEX FOR FORM NO. 927-1060

MODEL	SPEC.	DATED	FICHE	LOCATION
7.0CCK-3014	1T	12/01/78 **	* 1 F1	
7.0CCK-381E	4325T	12/01/78 **	* 1 F3	
7.0CCK-3816	8 874T	12/01/78 **	* 1 F3	
7.000K-381E	14917T	12/01/78 **	* 1 F5	/

SPECIA		RTS LIST FOR MODEL OR STANDARD PARTS REF		SPEC 927-1060	1T KEY NO1
		ARTS CATALOG ALSO CONTAINS C			
		WIRIN	IG DIAGRAM NO.	6	06-0156-01
PART NO.	QTY	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
		•			
201-1312	1	Rotor Assembly, Wound			
222-1675	1	Coil Assembly, Field			
		•			
			·		
					en en en en en en en en en en en en en e

SPECIAL PARTS LIST FOR MODEL ______7.0CCK-381E

FOR STANDARD PARTS REFER TO CATALOG 927-1060 _ KEY NO. __

(PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW)

WIRING DIAGRAM NO. 606-0156-01

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
				T	
201-1312	1	Rotor Assembly, Wound			`
222-1675	1	Coil Assembly, Field	·		

1

SPECIA		TS LIST FOR MODEL		OCCK-381E	SPEC _	8874T
		R STANDARD PARTS			927-1060	KEY NO
	(PAR	ITS CATALOG ALSO CONTA W		AGRAM NO.	•	
PART NO.	QTY.	DESCRIPTION	Titling Di			
FARTINO.	\(\text{\tin}\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\tin}\text{\ti}}\tint{\text{\text{\text{\text{\text{\text{\text{\text{\texi}}\tittt{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\text{\texi}\titt{\text{\texi}\tittit{\text{\text{\texi}\titt{\text{\texi}\tittitt{\text{\texit{\texi}\text{\text{\texi}\titt{\texitit}}\tinttitex{\text{\texi}}\texit{\text{\tex	DESCRIPTION		PART NO.	QTY.	DESCRIPTION
201-1312 222-1675	1 1	Rotor Assembly, Wour Coil Assembly, Field	nd 1			
149-1254	1	Primer, Fuel Pump				
149-1255	1	Bracket, Primer				
						,
		•				

Page_ 1 of

1

FOR STANDARD PARTS REFER TO CATALOG 927-1060 KEY NO. ___ (PARTS CATALOG ALSO CONTAINS COMPONENTS FOR MAJOR OPTIONAL FEATURES LISTED BELOW) 606-0156-01

WIRING DIAGRAM NO.

PART NO.	QTY.	DESCRIPTION	PART NO.	QTY.	DESCRIPTION
	T		.	T	
201-1312	1	Rotor Assembly, Wound			
222-1675	1	Coil Assembly, Field			